enger

Installation Manual for Aprile Handles and Rosettes
(Product code: AS QR 7S)

HANDLE
Set includes:

- A pair of handles – left and right – integrated with sub-handle rosettes
- 2 synthetic mounting rosettes (mounting adapters)
- Split spindle, 8x8 mm
- 2 through bolts (M4)
- Set of hex screws with key
- Set of wood screws

Handle installation:

1. Drill two holes for through bolts, diameter Ø 7.5 mm on both sides of the door, 38 mm apart. **Do not drill all the way through from one side.** Drill from both sides to avoid damaging the outer door surface.
   Use the installation template or a mounting adapter with a spindle stabilizing element to mark the hole positions.
   After drilling, break out the spindle stabilizing element from the adapters.
2. Use the included through bolts to screw together both mounting adapters.
   The securing tabs should face downward. The adapters are universal (left/right).
3. You can additionally secure the adapters with wood screws.
4. Assemble the spindle and insert it into the door lock with the notch facing downward, so that it protrudes equally on both sides.
5. Press the handle onto the mounted adapter and spindle. It should fit flush against the door surface.
6. Fasten the handles from underneath using the hex screws.

OB and PZ ROSETTE
Set includes:

- 2 covers
- 2 synthetic mounting rosettes (mounting adapters)
- 2 through bolts (M4)
- Set of wood screws

Rosette installation:

1. Drill two holes for through bolts, diameter Ø 7.5 mm on both sides of the door, 38 mm apart. Do not drill all the way through from one side. Drill from both sides to avoid damaging the door surface.
   Use the installation template to mark the holes.
   After drilling, break out the spindle stabilizing element from the adapters.
2. Use the included through bolts to screw together both mounting adapters.
   The securing tabs should face downward. The adapters are universal (left/right).
3. You can additionally secure the adapters with wood screws.
4. Press the rosette onto the mounted adapter. It should fit flush against the door surface.

enger

WC ROSETTE

Set includes:

- 2 covers
- 2 synthetic mounting rosettes (mounting adapters)
- 2 through bolts (M4)
- Set of hex screws with key
- WC turn knob with a 4x4 mm spindle (reduction adapter available separately)
- Set of wood screws

Rosette installation:

1. Drill two holes for through bolts, diameter Ø 7.5 mm on both sides of the door, 38 mm apart. Do not drill all the way through from one side. Drill from both sides to avoid damaging the door surface.
   Use the installation template to mark the holes.
   After drilling, break out the spindle stabilizing element from the adapters.
2. Use the included through bolts to screw together both mounting adapters.
   The securing tabs should face downward. The adapters are universal (left/right).
3. You can additionally secure the adapters with wood screws.
4. Press the rosette onto the mounted adapter. It should fit flush against the door surface.
5. Insert the spindle into the door lock. For magnetic locks, use a reducer to adjust the hole size for the WC spindle.
6. Use the hex screw to fasten the WC turn knob to the spindle.

Congratulations! You're done.