enger

Installation Manual for Sterk Handles and Rosettes
(Product code: SH OVAL 3MM, SH KVADRAT 3MM)

HANDLE
Set includes:

- A pair of handles:
  - Left handle – integrated with a sub-handle rosette
  - Right handle – integrated with a sub-handle rosette and a threaded mounting adapter
- Mounting adapter for the left handle
- Split spindle, 8x8 mm
- 2 M4 through bolts
- Set of hex screws with key

Handle installation:

1. Drill two holes for the through bolts, Ø 7.5 mm in diameter, on both sides of the door, 38 mm apart.
   Do not drill all the way through from one side. Drill from both sides to avoid damaging the outer surface of the door.
2. Insert the spindle into the door lock with the notch facing downward, ensuring equal length of the spindle on both sides of the door.
3. Remove the non-threaded mounting adapter from the left handle – it is held by magnets.
4. Use the included through bolts to fasten together the right handle and the left handle's mounting adapter.
5. Attach the left handle to the mounted adapter – the magnets will pull the parts together. The handle should sit flush against the door surface.
6. Fasten the handles from below using the hex screws.

OB and PZ ROSETTE
Set includes:

- 1 set of OB/PZ rosette with a non-threaded adapter (held together by a magnet – separate before installation)
- 1 set of OB/PZ rosette integrated with a threaded cover
- 2 M4 through bolts

Rosette installation:

1. Drill two holes for the through bolts, Ø 7.5 mm in diameter, on both sides of the door, 38 mm apart.
   Do not drill through from one side. Drill from both sides to protect the outer door layer.
2. Use the included through bolts to fasten the two mounting adapters together.
3. Attach the cover to the mounted adapter. The rosette should sit flush against the door surface.

enger

WC ROSETTE

Set includes:

- 1 set of rosette with a non-threaded adapter (magnetically attached) and WC spindle (turn knob shaft)
- 1 set of rosette integrated with a threaded cover and WC turn knob
- 2 M4 through bolts
- Hex screw with key
- 4/6 mm metal spindle reducer

Rosette installation:

1. Drill two holes for the through bolts, Ø 7.5 mm in diameter, on both sides of the door, 38 mm apart.
   Do not drill through from one side. Drill from both sides to avoid damaging the door surface.
2. Use the included through bolts to fasten the two mounting adapters together.
3. Insert the spindle into the door lock. For magnetic locks, use the included reducer to adjust the spindle hole diameter.
4. Attach the cover to the installed adapter and spindle. The rosette should sit flush with the door surface.
5. Screw the hex bolt into the turn knob to lock the spindle in place.

Congratulations! You're done.