enger

Sterk PRO Handle and Rosette Installation Manual
(Product code: SH PRO 8MM)

HANDLE
Set includes:

- A pair of handles – left and right – integrated with mounting adapters
- 2 threaded covers
- Handle spindle, 8x8 mm
- 2 M4 through bolts
- Set of hex screws with Allen key

Handle installation:

1. Drill two holes for the through bolts, Ø 7.5 mm in diameter, on both sides of the door, spacing 38 mm.
   Do not drill through from only one side. Drill from both sides to prevent damaging the outer surface of the door.
2. Insert the spindle into the door lock with the notch facing downward, ensuring equal length on both sides of the door.
3. Before installation, protect the handle from damage.
4. Use the included through bolts to fasten together both mounting adapters with the handles.
5. Screw the threaded covers onto the installed handles. The handle should sit flush against the door surface.
6. Fasten the handles from below using the hex screws.

OB and PZ ROSETTE
Set includes:

- 2 threaded covers
- 2 metal mounting rosettes (mounting adapters)
- 2 M4 through bolts

Rosette installation:

1. Drill two holes for the through bolts, Ø 7.5 mm in diameter, on both sides of the door, spacing 38 mm.
   Do **not** drill through from one side. Drill from both sides to avoid damaging the door's outer surface.
2. Use the included through bolts to fasten the two mounting adapters together.
3. Screw the cover onto the mounted adapter. The rosette should sit flush against the door surface.

WC ROSETTE
Set includes:

- 1 rosette with adapter and turn knob (non-detachable)
- 1 mounting rosette with threaded cover and indicator (detachable)

enger

- 2 M4 through bolts
- Spindle 4x4 mm
- 4/6 mm metal reducer

Rosette installation:

1. Drill two holes for the through bolts, Ø 7.5 mm in diameter, on both sides of the door, spacing 38 mm.
   Do not drill through from one side. Drill from both sides to avoid damaging the outer surface of the door.
2. Use the included through bolts to fasten the two mounting adapters together.
3. Insert the spindle into the door lock. For magnetic locks, use the included reducer to adjust the spindle hole diameter.
4. Place and screw the rosette onto the mounted adapter and spindle. The rosette should sit flush against the door surface.

Congratulations! You're done.