enger

Installation Instructions for Sterk Brand Handles, Knobs, and Rosettes
(Product Code: SM OVAL, SM KVADRAT)

HANDLE
Set includes:

- A pair of handles – left and right – integrated with mounting adapters
- 2 cover plates
- Split spindle, 8x8 mm
- 2 through screws M4
- Set of hex screws with Allen keys

Handle Installation:

1. Drill two holes Ø 7.5 mm for through screws on both sides of the door, spacing 38 mm. Do not drill all the way through from one side – always drill partially from each side to avoid damaging the door surface.
2. Insert the spindle into the door lock with the notch facing down, so that it protrudes equally on both sides.
3. Use the included through screws to fasten the two mounting adapters with the handles.
4. Press the cover plates onto the installed handle set. The handle should sit flush against the door surface.
5. Fasten the handles from underneath using the hex screws.

ROSETTE OB and PZ
Set includes:

- 2 cover plates
- 2 mounting rosettes (metal mounting adapters)
- 2 through screws M4

Rosette Installation:

1. Drill two holes Ø 7.5 mm for through screws on both sides of the door, spacing 38 mm. Do not drill all the way through from one side – always drill partially from each side to avoid damaging the door surface.
2. Use the included through screws to fasten the two metal mounting adapters.
3. Press the cover plates onto the mounted adapters. The rosette should sit flush against the door surface.

WC ROSETTE
Set includes:

- 2 cover plates
- 2 mounting rosettes (mounting adapters)
- 2 through screws M4
- Hex screw with Allen key
- WC turn knob with 4x4 mm spindle (a reducer can be ordered separately)

WC Rosette Installation:

1. Drill two holes Ø 7.5 mm for through screws on both sides of the door, spacing 38 mm. Do not drill all the way through from one side – always drill partially from each side to avoid damaging the door surface.
2. Use the included through screws to fasten the two mounting adapters.

enger

3. Insert the spindle into the door lock. For magnetic locks, use the reducer to adjust the hole diameter to fit the WC spindle.
4. Place the rosette onto the mounted adapter and spindle, then fasten it from underneath using the hex screw. The rosette should sit flush against the door surface.
5. Attach the WC turn knob to the spindle using the hex screw.

Congratulations! You're done.