enger

Assembly instructions for Stile door handles and rosettes
(Product code: ST R 7S, ST Q 7S)

HANDLES
The set includes:
- a pair of handles - left and right; combined with roses;
- 2 pcs. of mounting roses (so-called mounting adapters);
- handle stem 8x8 mm (two-part);
- 2 pcs. of through bolts M4;
- a set of Allen screws and spanners.

Assembly of the handle:

1. Drill 2 Ø 7.5 mm holes on both sides of the door with 38 mm spacing for through bolts. Do not drill through the door on one side. Ream the holes on both sides to avoid damaging the outer layer of the door. You can either use a mounting template to mark the holes or use a mounting adapter with a stabilising pin. After preparing the screw holes, break out the stem stabiliser from the adapters.
2. Use the supplied bolts and screw the two mounting adapters together. These elements shall be oriented with the safety notch downwards.
3. You can additionally stabilise the mounting adapters with wood screws. Screws are not included.
4. Fold the pin and insert it into the door lock with the notch facing downwards so that the length of the pin is the same on both sides of the door.
5. Place the handle on the adapter and pin thus installed. The handle shall be flush with the door.
6. Screw the handle rose from below to the adapter.
7. Fasten the handles from below with Allen screws.

ROSES OB and PZ
The set includes:
- 2 pcs. rosette covers;
- 2 pcs. of mounting roses (so-called mounting adapters);
- 2 pcs. of through bolts M4;
- a set of Allen screws and spanners;

Assembly of the rosette:

1. Drill 2 Ø 7.5 mm holes on both sides of the door with 38 mm spacing for through bolts. Do not drill through the door on one side. Ream the holes on both sides to avoid damaging the outer layer of the door. You can use the installation template to mark the hole locations. After preparing the screw holes, break out the stem stabiliser from the adapters.
2. Use the supplied bolts and screw the two mounting adapters together. These elements shall be oriented with the safety notch downwards. The adapters are universal (right/left).
3. You can additionally stabilise the mounting adapters with wood screws. Screws are not included.
4. Place the rose on the mounted adapter and fasten it from below with an Allen screw. The rose should sit flush against the door.

enger

WC ROSES

<u>The set includes:</u>

- 2 pcs. rosette covers;
- 2 pcs. of mounting roses (so-called mounting adapters);
- 2 pcs. of through bolts M4;
- a set of Allen screws and spanners
- WC knob with handle stem 4x4 mm (it is possible to order an additional reduction).

Assembly of the rosette:

1. Drill 2 Ø 7.5 mm holes on both sides of the door with 38 mm spacing for through bolts. Do not drill through the door on one side. Ream the holes on both sides to avoid damaging the outer layer of the door. You can use a mounting adapter to mark the hole locations. After preparing the screw holes, break out the stem stabiliser from the adapters.
2.
3. You can additionally stabilise the mounting adapters with wood screws.
4. Slide the stem into the door lock. For magnetic locks, use a reduction to change the diameter of the hole for the W.C. stem.
5. Place the rose over the mounted adapter and stem thus installed and fasten it from below with an Allen screw. The rose should fit flush with the door.
6. Screw the knob of the W.C. rose to the stem with the Allen screw.

Congratulations! That is all.